

PART NUMBER	DESCRIPTION	MANUFACTURER
103432-1	VALVE, OUTFLOW	HONEYWELL
114079001	VALVE	MESSIER-DOWTY
114079002	VALVE	MESSIER-DOWTY
114079005	VALVE	MESSIER-DOWTY
114079006	VALVE	MESSIER-DOWTY
114079009	VALVE	MESSIER-DOWTY
114079010	VALVE	MESSIER-DOWTY
114079012	VALVE	MESSIER-DOWTY
114079013	VALVE	MESSIER-DOWTY
114079014	VALVE	MESSIER-DOWTY
114079015	VALVE	MESSIER-DOWTY
114079016	VALVE	MESSIER-DOWTY
114079017	VALVE	MESSIER-DOWTY
114080001	VALVE	MESSIER-DOWTY
114080003	VALVE	MESSIER-DOWTY
114083003	VALVE	MESSIER-DOWTY
114086001	VALVE	MESSIER-DOWTY
114087001	BYPASS VALVE	SMITHS
114087002	BYPASS VALVE	SMITHS
114087003	BYPASS VALVE	SMITHS
114087004	BYPASS VALVE	SMITHS
114087005	VALVE	MESSIER-DOWTY
114087006	BYPASS VALVE	SMITHS
114087007	BYPASS VALVE	SMITHS
114093003	ACTUATOR	MESSIER-DOWTY
114095001	LOCK STAY ACTUATOR	MESSIER-DOWTY
114095001	LOCK STAY ACTUATOR	MESSIER-DOWTY
114095002	LOCK STAY ACTUATOR	MESSIER-DOWTY
114095002	ACTUATOR	MESSIER-DOWTY
114095003	LOCK STAY ACTUATOR	MESSIER-DOWTY
114095004	LOCK STAY ACTUATOR	MESSIER-DOWTY
114120010	ACTUATOR	MESSIER-DOWTY

PART NUMBER	DESCRIPTION	MANUFACTURER
114122003	ACTUATOR	MESSIER-DOWTY
114122004	ACTUATOR	MESSIER-DOWTY
114122006	ACTUATOR	MESSIER-DOWTY
114122007	ACTUATOR	MESSIER-DOWTY
114122008	ACTUATOR	MESSIER-DOWTY
114122009	MLG DOOR ACTUATOR	SMITHS
114151001	VALVE, RELIEF	MESSIER-DOWTY
114151002	VALVE, RELIEF	MESSIER-DOWTY
114151003	VALVE, RELIEF	MESSIER-DOWTY
114151004	VALVE, RELIEF	MESSIER-DOWTY
114151005	VALVE, RELIEF	MESSIER-DOWTY
114153001	VALVE, RELIEF	MESSIER-DOWTY
114153002	VALVE, RELIEF	MESSIER-DOWTY
114160003	ACTUATOR	MESSIER-DOWTY
114160003	EJECTION JACK	HAMILTON SUNDSTRAND
114160004	ACTUATOR	MESSIER-DOWTY
114160004	EJECTION JACK	HAMILTON SUNDSTRAND
114160004A	EJECTION JACK	HAMILTON SUNDSTRAND
114160005	EJECTION JACK	HAMILTON SUNDSTRAND
114160005	ACTUATOR	MESSIER-DOWTY
114170001	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170002	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170003	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170004	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170005	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170006	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170007	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
114170008	SELECTOR MANIFOLD ASSY	MESSIER-DOWTY
11419007	ACTUATOR	MESSIER-DOWTY
114193001	ACTUATOR	MESSIER-DOWTY
114193002	ACTUATOR	MESSIER-DOWTY
114193003	ACTUATOR	MESSIER-DOWTY
114193005	ACTUATOR	MESSIER-DOWTY
114193006	ACTUATOR	MESSIER-DOWTY
121664-3	BALL SCREW ACTUATOR	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
121664-353	BALL SCREW ACTUATOR	HONEYWELL
121664-354	BALL SCREW ACTUATOR	HONEYWELL
121664-355	BALL SCREW ACTUATOR	HONEYWELL
121664-4	BALL SCREW ACTUATOR	HONEYWELL
121664-5	BALL SCREW ACTUATOR	HONEYWELL
121666-11	BALL SCREW ACTUATOR	HONEYWELL
121666-13	BALL SCREW ACTUATOR	HONEYWELL
121666-14	BALL SCREW ACTUATOR	HONEYWELL
121666-15	BALL SCREW ACTUATOR	HONEYWELL
121666-16	BALL SCREW ACTUATOR	HONEYWELL
121666-17	BALL SCREW ACTUATOR	HONEYWELL
121666-18	BALL SCREW ACTUATOR	HONEYWELL
121666-19	BALL SCREW ACTUATOR	HONEYWELL
121666-21	BALL SCREW ACTUATOR	HONEYWELL
121666-3	BALL SCREW ACTUATOR	HONEYWELL
121666-353	BALL SCREW ACTUATOR	HONEYWELL
121666-355	BALL SCREW ACTUATOR	HONEYWELL
121666-4	BALL SCREW ACTUATOR	HONEYWELL
121666-5	BALL SCREW ACTUATOR	HONEYWELL
121666-6	BALL SCREW ACTUATOR	HONEYWELL
121666-7	BALL SCREW ACTUATOR	HONEYWELL
121666-8	BALL SCREW ACTUATOR	HONEYWELL
121666-9	BALL SCREW ACTUATOR	HONEYWELL
1263A0000-02	AIR CYCLE MACHINE	LIEBHERR
1303A0000-01	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-02	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-02 Amdt B	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-03	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-03 Amdt A	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-03 Amdt AB	VALVE, FLOW CONTROL	LIEBHERR
1303A0000-03 Amdt B	VALVE, FLOW CONTROL	LIEBHERR
1320A0000-01	TRIM AIR VALVE	LIEBHERR
1553A9900-01	MANIFOLD, HP	LIEBHERR
1554A9900-01	MANIFOLD, HP	LIEBHERR
1555A9900-01	MANIFOLD, HP, PTU	LIEBHERR

PART NUMBER	DESCRIPTION	MANUFACTURER
--------------------	--------------------	---------------------

1555B9900-01	MANIFOLD, HP, PTU	LIEBHERR
1559A9900-01	MANIFOLD, HP	LIEBHERR
1559A9900-01	MANIFOLD, HP	LIEBHERR
201042297	DAMPER	MESSIER-DOWTY
201117011	UPLOCK	MESSIER-DOWTY
201117012	UPLOCK	MESSIER-DOWTY
201117013	UPLOCK	MESSIER-DOWTY
201117014	UPLOCK	MESSIER-DOWTY
201122004	UPLOCK	MESSIER-DOWTY
201122006	UPLOCK	MESSIER-DOWTY
201179001	ACTUATOR ASSY-UPLOCK, MLG	SMITHS
201180001	ACTUATOR ASSY-UPLOCK, MLG DOOR	SMITHS
201404001	DAMPER	MESSIER-DOWTY
201419001	DAMPER	MESSIER-DOWTY
201419001-010	DAMPER	MESSIER-DOWTY
20645	ACTUATING CYLINDER	MESSIER BUGATTI
20645-000-01	ACTUATING CYLINDER	MESSIER BUGATTI
2290A02	VALVE, CHECK	LIEBHERR
2290A030000	VALVE, CHECK	LIEBHERR
2290A040000	VALVE, CHECK	LIEBHERR
2290A050000	VALVE, CHECK	LIEBHERR
2290B010000	CHECK VALVE	LIEBHERR
2290B020000	CHECK VALVE	LIEBHERR
2293B010000	CHECK VALVE	LIEBHERR
2293B020000	CHECK VALVE	LIEBHERR
24730001-4	UPLOCK	MESSIER-DOWTY
2770555-101	VALVE, SOLENOID	PARKER
2770561-101	VALVE, SOLENOID	PARKER
2790583-108	VALVE, ANTI-ICE	PARKER
301-774-703-0	BLEED VALVE	HONEYWELL
301-774-704-0	BLEED VALVE	HONEYWELL
301-783-701-0	VALVE	HONEYWELL
301-785-501-0	PUMP	HONEYWELL
301-785-502-0	PUMP	HONEYWELL
301-787-701-0	VALVE	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
301-787-702-0	VALVE	HONEYWELL
32-01066-1	VALVE, ANTI-ICE	JANITROL
32-01066-3	VALVE, ANTI-ICE	JANITROL
321-400-703-0	ACTUATOR	HONEYWELL
321-400-704-0	ACTUATOR	HONEYWELL
321-400-705-1	ACTUATOR	HONEYWELL
321-400-705-2	ACTUATOR	HONEYWELL
321-400-705-3	ACTUATOR	HONEYWELL
321-400-705-4	ACTUATOR	HONEYWELL
321-400-705-5	ACTUATOR	HONEYWELL
32-3110-004	VALVE, ANTI-ICE	JANITROL
32-3110-005	VALVE, ANTI-ICE	JANITROL
32-3110-006	VALVE, ANTI-ICE	JANITROL
324195-1	VALVE, ANTI-ICE	HONEYWELL
3290052-1	VALVE, SHUT-OFF	HONEYWELL
3290052-2	VALVE, SHUT-OFF	HONEYWELL
3290064-10	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-13	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-15	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-17	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-18	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-19	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-2	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3290064-3	FOUR INCH DIAMETER STARTER VALVE ASSEMB	HONEYWELL
3291432-1	VALVE, CONTROL	HONEYWELL
3505582-1	AIR TURBINE STARTER	HONEYWELL
3505582-12	AIR TURBINE STARTER	HONEYWELL
3505582-14	AIR TURBINE STARTER	HONEYWELL
3505582-15	AIR TURBINE STARTER	HONEYWELL
3505582-2	AIR TURBINE STARTER	HONEYWELL
3505582-22	AIR TURBINE STARTER	HONEYWELL
3505582-23	AIR TURBINE STARTER	HONEYWELL
3505582-24	AIR TURBINE STARTER	HONEYWELL
3505582-25	AIR TURBINE STARTER	HONEYWELL
3505582-3	AIR TURBINE STARTER	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
3505582-4	AIR TURBINE STARTER	HONEYWELL
3505582-40	AIR TURBINE STARTER	HONEYWELL
3505582-41	AIR TURBINE STARTER	HONEYWELL
3505582-42	AIR TURBINE STARTER	HONEYWELL
3505582-60	AIR TURBINE STARTER	HONEYWELL
3505582-61	AIR TURBINE STARTER	HONEYWELL
3505582-62	AIR TURBINE STARTER	HONEYWELL
3800708-1	VALVE, LOAD CONTROL	HONEYWELL
3880050-101	ACTUATOR	HONEYWELL
3880140-1	VALVE	HONEYWELL
3880140-2	VALVE	HONEYWELL
3880140-3	VALVE	HONEYWELL
3880140-4	VALVE	HONEYWELL
3883297-2	FLOW DIVIDER	HONEYWELL
3883297-4	FLOW DIVIDER	HONEYWELL
3883297-5	FLOW DIVIDER	HONEYWELL
3883297-6	FLOW DIVIDER	HONEYWELL
38E93-4	VALVE, ANTI-ICE	HONEYWELL
38E93-5	VALVE, ANTI-ICE	HONEYWELL
410-1888	VALVE, FLOW CONTROL	PARKER
4140066-6	VALVE	HONEYWELL
4140066-7	VALVE	HONEYWELL
4140066-8	VALVE	HONEYWELL
4141028-1	DEPRIME VALVE	HONEYWELL
4141028-2	DEPRIME VALVE	HONEYWELL
4141028-3	DEPRIME VALVE	HONEYWELL
4141028-4	DEPRIME VALVE	HONEYWELL
4203501	HYDRAULIC MOTOR	PARKER
4203502	HYDRAULIC MOTOR	PARKER
42049	HYDRAULIC MOTOR	PARKER
42056	HYDRAULIC PUMP	PARKER
42057	HYDRAULIC PUMP	PARKER
42E35-1	VALVE, ANTI-ICE	JANITROL
43277	HYDRAULIC PUMP	PARKER
518150	HYDRAULIC PUMP	VICKERS

PART NUMBER	DESCRIPTION	MANUFACTURER
518157	HYDRAULIC MOTOR	VICKERS
518203	HYDRAULIC PUMP	VICKERS
623977	HYDRAULIC PUMP	VICKERS
6331-16639	ACTUATOR	PARKER
65-17823-1	BYPASS VALVE	SMITHS
6713B02	VALVE	LIEBHERR
6713B03	VALVE	LIEBHERR
6713C010000	VALVE, REGULATOR	LIEBHERR
6713D010000	VALVE, REGULATOR	LIEBHERR
6713D020000	VALVE, REGULATOR	LIEBHERR
6713D040000	VALVE, REGULATOR	LIEBHERR
6713D040000+A	VALVE, REGULATOR	LIEBHERR
6713D050000	VALVE, REGULATOR	LIEBHERR
6713D050000+A	VALVE, REGULATOR	LIEBHERR
6713D060000	VALVE, REGULATOR	LIEBHERR
6713D060000+A	VALVE, REGULATOR	LIEBHERR
6713D070000	VALVE, REGULATOR	LIEBHERR
6713D070000+A	VALVE, REGULATOR	LIEBHERR
6714A03	VALVE	LIEBHERR
6714B01	VALVE	LIEBHERR
6714B02	VALVE	LIEBHERR
6714C010000	VALVE	LIEBHERR
6714D010000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D020000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D040000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D050000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D060000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D060000	VALVE, PRESSURE REGULATING	LIEBHERR
6714D060000+A	VALVE, PRESSURE REGULATING	LIEBHERR
6714D060000+B	VALVE, PRESSURE REGULATING	LIEBHERR
6714D070000	HP BLEED VALVE	LIEBHERR
6714D070000 AMDT A	HP BLEED VALVE	LIEBHERR
6730A02	VALVE, FAN AIR	LIEBHERR
6730B01000	VALVE	LIEBHERR
6730B02	VALVE, FAN AIR	LIEBHERR

PART NUMBER	DESCRIPTION	MANUFACTURER
6730C01000	VALVE, FAN AIR	LIEBHERR
6730C01000+A	FAN AIR VALVE	LIEBHERR
6740B03000	VALVE, OVER PRESSURE	LIEBHERR
6740B04000	VALVE, OVER PRESSURE	LIEBHERR
6740B05000	VALVE, OVER PRESSURE	LIEBHERR
6740E01000	VALVE, OVER PRESSURE	LIEBHERR
6753B040000	HP REGULATING VALVE	LIEBHERR
6763C070000	HP BLEED VALVE	LIEBHERR
6763C080000	HP BLEED VALVE	LIEBHERR
6763C080000 AMDT A	HP BLEED VALVE	LIEBHERR
6763D080000	HP BLEED VALVE	LIEBHERR
6763D090000	HP BLEED VALVE	LIEBHERR
6763D090000 AMDT A	HP BLEED VALVE	LIEBHERR
6773B02000	VALVE, PRESSURE	LIEBHERR
6773E01000	VALVE, PRESSURE	LIEBHERR
6773E010000	HP REGULATING VALVE	LIEBHERR
6773E010000 AMDT A	HP REGULATING VALVE	LIEBHERR
6773E010000 AMDT A	HP REGULATING VALVE	LIEBHERR
6773E010000 AMDT B	HP REGULATING VALVE	LIEBHERR
6773F010000	HP BLEED VALVE	LIEBHERR
6773F010000 AMDT A	HP BLEED VALVE	LIEBHERR
6773G010000	HP BLEED VALVE	LIEBHERR
6774E010000	VALVE, BLEED	LIEBHERR
6774E010000 Amdt A	VALVE, BLEED	LIEBHERR
6774E010000 Amdt AB	VALVE, BLEED	LIEBHERR
6774E010000 Amdt AB	VALVE, BLEED	LIEBHERR
6774E010000 Amdt AC	VALVE, BLEED	LIEBHERR
6774E010000 Amdt C	VALVE, BLEED	LIEBHERR
6774E02000	VALVE, PRESSURE	LIEBHERR
6774F010000	BLEED VALVE	LIEBHERR
6774F010000 AMDT A	BLEED VALVE	LIEBHERR
6774F010000 AMDT A	BLEED VALVE	LIEBHERR
6774G010000	BLEED VALVE	LIEBHERR
6774G010000 AMDT A	BLEED VALVE	LIEBHERR
680203019	TURBINE PUMP	HAMILTON SUNDSTRAND

PART NUMBER	DESCRIPTION	MANUFACTURER
680203020	TURBINE PUMP	HAMILTON SUNDSTRAND
680203021	TURBINE PUMP	HAMILTON SUNDSTRAND
693335	HYDRAULIC PUMP	VICKERS
693337	HYDRAULIC MOTOR	VICKERS
693830	HYDRAULIC PUMP	VICKERS
71190400010NO	VALVE	HAMILTON SUNDSTRAND
714900-1	PUMP	HAMILTON SUNDSTRAND
714900-2	PUMP	HAMILTON SUNDSTRAND
714900-3	PUMP	HAMILTON SUNDSTRAND
714900-4	PUMP	HAMILTON SUNDSTRAND
73016	VALVE, FLOW CONTROL	PARKER
733756	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
733757	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
74000	PRIMARY LOCK	PARKER
745A0000-01	VALVE	LIEBHERR
746078-1	MASTER CYLINDER	MESSIER BUGATTI
746078-101	MASTER CYLINDER	MESSIER BUGATTI
746078-102	MASTER CYLINDER	MESSIER BUGATTI
746A0000-04	VALVE, PRESSURE REG	LIEBHERR
746A0000-05	VALVE, PRESSURE REG	LIEBHERR
746A0000-06	VALVE, PRESSURE REG	LIEBHERR
747743	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
747744	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
748A0000-05	VALVE	LIEBHERR
749198-1	HYDRAULIC RESERVOIR	MESSIER BUGATTI
749198-2	HYDRAULIC RESERVOIR	MESSIER BUGATTI
750A0000-02	VALVE	LIEBHERR
750A0000-02	VALVE	LIEBHERR
751A0000-07	VALVE, FLOW CONTROL	LIEBHERR
751B0000-02	VALVE, FLOW CONTROL	LIEBHERR
751B0000-02+A	VALVE, FLOW CONTROL	LIEBHERR
751B0000-02+B	VALVE, FLOW CONTROL	LIEBHERR
751F0000-01	VALVE, FLOW CONTROL	LIEBHERR
757A0000-08	AIR CYCLE MACHINE	LIEBHERR
757A0000-09	AIR CYCLE MACHINE	LIEBHERR

PART NUMBER	DESCRIPTION	MANUFACTURER
757A0000-10	AIR CYCLE MACHINE	LIEBHERR
758A0000-02	VALVE, BYPASS	LIEBHERR
758A0000-02+A	VALVE, BYPASS	LIEBHERR
762080	VALVE, SAFETY	MESSIER BUGATTI
762080-1	VALVE, SAFETY	MESSIER BUGATTI
762080-2	VALVE, SAFETY	MESSIER BUGATTI
762080-3	VALVE, SAFETY	MESSIER BUGATTI
762A0000-04	ACTUATOR	LIEBHERR
766238	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
766239	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
766261	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
766262	HYDRAULIC PUMP	HAMILTON SUNDSTRAND
769A0000-01	VALVE	LIEBHERR
769A0000-02	VALVE	LIEBHERR
777A0000-01	VALVE, SELECTOR	LIEBHERR
786A0000-12	POWER CONTROL UNIT	LIEBHERR
786A2000-01	PRESSURE-OFF BRAKE	LIEBHERR
787A0000-07	VALVE BLOCK	LIEBHERR
788A0000-01	GEARBOX	LIEBHERR
789A0000-01	GEARBOX	LIEBHERR
790424-4	VALVE, STARTER CONTROL	HAMILTON SUNDSTRAND
790425-2	VALVE, STARTER CONTROL	HAMILTON SUNDSTRAND
790A0000-02	GEARBOX	LIEBHERR
791A0000-02	FLAP ACTUATOR	LIEBHERR
791A0000-03	FLAP ACTUATOR	LIEBHERR
791A0000-04	FLAP ACTUATOR	LIEBHERR
791A0000-05	FLAP ACTUATOR	LIEBHERR
791A0000-06	FLAP ACTUATOR	LIEBHERR
791C0000-01	FLAP ACTUATOR	GOODRICH
793A0000-03	FLAP ACTUATOR	GOODRICH (LIEBHERR)
793A0000-04	FLAP ACTUATOR	GOODRICH (LIEBHERR)
793A0000-05	FLAP ACTUATOR	GOODRICH (LIEBHERR)
793A0000-06	FLAP ACTUATOR	GOODRICH (LIEBHERR)
793A0000-07	FLAP ACTUATOR	GOODRICH (LIEBHERR)
7940061D	VALVE	LIEBHERR

PART NUMBER	DESCRIPTION	MANUFACTURER
794A0000-02	FLAP ACTUATOR	GOODRICH (LIEBHERR)
794A0000-03	FLAP ACTUATOR	GOODRICH (LIEBHERR)
794A0000-04	FLAP ACTUATOR	GOODRICH (LIEBHERR)
794A0000-05	FLAP ACTUATOR	GOODRICH (LIEBHERR)
794A0000-06	FLAP ACTUATOR	GOODRICH (LIEBHERR)
810A0000-03	RUDDER SERVO CONTROL	LIEBHERR
810A0000-04	RUDDER SERVO CONTROL	LIEBHERR
810A0000-04A	RUDDER SERVO CONTROL	LIEBHERR
810A0000-04B	RUDDER SERVO CONTROL	LIEBHERR
810A0000-05	RUDDER SERVO CONTROL	LIEBHERR
810A0300-03	VALVE, BLOCK	LIEBHERR
810A0300-04	VALVE, BLOCK	LIEBHERR
811A0000-02	CYLINDER ASSEMBLY	LIEBHERR
811A0000-03	CYLINDER ASSEMBLY	LIEBHERR
811A0000-04	CYLINDER ASSEMBLY	LIEBHERR
827A0000-01	GEARBOX	LIEBHERR
828A0000-01	GEARBOX	LIEBHERR
829A0000-01	ACTUATOR	LIEBHERR
831A0000-01	WING-TIP BRAKE	LIEBHERR
831A0000-02	WING-TIP BRAKE	LIEBHERR
831A0000-03	WING-TIP BRAKE	LIEBHERR
831A0000-04	WING-TIP BRAKE	LIEBHERR
831A0000-05	WING-TIP BRAKE	LIEBHERR
831B0000-01	WING-TIP BRAKE	LIEBHERR
831C0000-01	WING-TIP BRAKE	LIEBHERR
887111	HYDRAULIC PUMP	VICKERS
887673	HYDRAULIC PUMP	VICKERS
920635	RELIEF VALVE	EATON AEROSPACE
96D08-1	VALVE, ANTI-ICE	JANITROL
97D57-1	VALVE, ANTI-ICE	JANITROL
986F12-1	NON-RETURN VALVE	INTERTECHNIQUE
A25312-1	VALVE	MESSIER BUGATTI
A25312-3	VALVE	MESSIER BUGATTI
A25313	VALVE, SELECTOR	MESSIER BUGATTI
A25313002	VALVE, SELECTOR	MESSIER BUGATTI

PART NUMBER	DESCRIPTION	MANUFACTURER
A25313002-1	VALVE, SELECTOR	MESSIER BUGATTI
A25313003	VALVE, SELECTOR	MESSIER BUGATTI
A25313-1	VALVE, SELECTOR	MESSIER BUGATTI
A25313-101	VALVE, SELECTOR	MESSIER BUGATTI
A25315	PARKING BRAKE VALVE	MESSIER BUGATTI
A25315-1	PARKING BRAKE VALVE	MESSIER BUGATTI
A25316	VALVE, SHUTTLE	MESSIER BUGATTI
A25316-1	VALVE, SHUTTLE	MESSIER BUGATTI
A25430001	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25430001-1	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25430001-2	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25431001	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25431001-1	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25431001-2	UPLOCK ASSEMBLY	MESSIER BUGATTI
A25434005	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-1	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-100	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-101	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-110	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-2	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-201	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-210	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-3	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-300	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-301	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-310	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-4	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-400	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-401	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434005-410	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-1	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-100	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-110	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-110	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI

PART NUMBER	DESCRIPTION	MANUFACTURER
A25434006-2	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-200	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-210	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25434006-3	VALVE, EMERGENCY BRAKE	MESSIER BUGATTI
A25460-2	AUTOMATIC SELECTOR	MESSIER BUGATTI
A25461-1	AUTOMATIC SELECTOR	MESSIER BUGATTI
A25461-102	AUTOMATIC SELECTOR	MESSIER BUGATTI
A25461-103	AUTOMATIC SELECTOR	MESSIER BUGATTI
A25461-104	AUTOMATIC SELECTOR	MESSIER BUGATTI
A25461-1-1	AUTOMATIC SELECTOR	MESSIER BUGATTI
A88008-02	VALVE	MESSIER BUGATTI
AP1V-060-02	HYDRAULIC PUMP	PARKER
B17CA1041	VALVE, PRESSURE REGULATING	LIEBHERR
B17CA1042	VALVE, PRESSURE REGULATING	LIEBHERR
C20374000-1	VALVE, BRAKE SERVO	MESSIER BUGATTI
C20374000-2	VALVE, BRAKE SERVO	MESSIER BUGATTI
C24343-1	VALVE, BYPASS SEQUENCE	MESSIER BUGATTI
C24592000	MASTER CYLINDER	MESSIER BUGATTI
C24592000-1	MASTER CYLINDER	MESSIER BUGATTI
C24592020	MASTER CYLINDER	MESSIER BUGATTI
C24730000-2	UPLOCK, NLG	MESSIER BUGATTI
C24730000-3	UPLOCK, NLG	MESSIER BUGATTI
C24730000-4	UPLOCK, NLG	MESSIER BUGATTI
C24730000-5	UPLOCK, NLG	MESSIER BUGATTI
C24730001-2	UPLOCK, NLG	MESSIER-DOWTY
C24730001-3	UPLOCK, NLG	MESSIER BUGATTI
C24730001-4	UPLOCK, NLG	MESSIER BUGATTI
C24730001-6	UPLOCK, NLG	MESSIER BUGATTI
C24730100	UPLOCK, NLG	MESSIER BUGATTI
C24736000	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736000-0-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736000-1	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736000-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736001	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736001-0-1	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI

PART NUMBER	DESCRIPTION	MANUFACTURER
C24736001-0-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736001-1	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24736001-2	HYDRAULIC CONTROL UNIT	MESSIER BUGATTI
C24757000	VALVE	MESSIER BUGATTI
C24784000	VALVE	MESSIER BUGATTI
C24792000	VALVE	MESSIER BUGATTI
C24792000-1	VALVE	MESSIER BUGATTI
C24792000-1	VALVE	MESSIER BUGATTI
C24792000-1A	VALVE	MESSIER BUGATTI
C24792000-1B	VALVE	MESSIER BUGATTI
C24792000-1D	VALVE	MESSIER BUGATTI
C24792000-2	VALVE	MESSIER BUGATTI
C24792000-2	VALVE	MESSIER BUGATTI
C247992000B	VALVE	MESSIER BUGATTI
C24828000	SWITCH	MESSIER BUGATTI
C25149000	VALVE	MESSIER BUGATTI
C25149000-1	VALVE	MESSIER BUGATTI
C25243002	VALVE, SAFETY	MESSIER BUGATTI
C25243002-1	VALVE, SAFETY	MESSIER BUGATTI
C25243002-2	VALVE, SAFETY	MESSIER BUGATTI
C25243102	VALVE, SAFETY	MESSIER BUGATTI
D026-001	SERVOVALVE, SPOILER	MOOG
D212741500000	VALVE	AEROSPATIALE
D212741500020	VALVE	AEROSPATIALE
D22426000	PITCH DAMPER	MESSIER BUGATTI
D22426000-1	PITCH DAMPER	MESSIER BUGATTI
D22426000-2	PITCH DAMPER	MESSIER BUGATTI
D22426000-3	PITCH DAMPER	MESSIER BUGATTI
D23071001	CYLINDER	MESSIER-DOWTY
D23076000-3	ACTUATOR	MESSIER-DOWTY
D23090000-2	ACTUATOR	MESSIER-DOWTY
D23090000-3	ACTUATOR	MESSIER-DOWTY
D23090000-4	ACTUATOR	MESSIER-DOWTY
D23090000-5	ACTUATOR	MESSIER-DOWTY
D23090000-6	ACTUATOR	MESSIER-DOWTY

PART NUMBER	DESCRIPTION	MANUFACTURER
D2711004000000	YAW DAMPER	AEROSPATIALE
D2711004000100	YAW DAMPER	AEROSPATIALE
MPEV3-032-10A	HYDRAULIC PUMP	VICKERS
MPEV3-032-10B	HYDRAULIC PUMP	VICKERS
PMP1V-016-01	HYDRAULIC PUMP	PARKER
PMP1V-016-02	HYDRAULIC PUMP	PARKER
PV3-240-10	HYDRAULIC PUMP	VICKERS
PV3-240-10A	HYDRAULIC PUMP	VICKERS
PV3-240-10C	HYDRAULIC PUMP	VICKERS
QA07739	RESERVOIR PRESSURISATION UNIT	PALL AEROSPACE
QA07739-01	RESERVOIR PRESSURISATION UNIT	PALL AEROSPACE
QA07739-02	RESERVOIR PRESSURISATION UNIT	PALL AEROSPACE
S252T001-4	VALVE, FLOW CONTROL	PARKER