

PART NUMBER	DESCRIPTION	MANUFACTURER
102150	VALVE	HONEYWELL
102150-0	VALVE	HONEYWELL
102150-0-12	VALVE	HONEYWELL
102150-0-13	VALVE	HONEYWELL
102196-2	AIRCRAFT CABIN AIR PRESSURE REGULATOR	HONEYWELL
103036-3	CABIN AIR PRESSURE SAFETY VALVE	HONEYWELL
103036-5	SAFETY VALVE	HONEYWELL
106040	AIR FLOW REGULATOR	HONEYWELL
106040-2	AIR FLOW REGULATOR	HONEYWELL
106040-3	AIR FLOW REGULATOR	HONEYWELL
106040-4-1	AIR FLOW REGULATOR	HONEYWELL
106388	SHUTOFF VALVE	HONEYWELL
106388-1-2	SHUTOFF VALVE	HONEYWELL
106388-3-1	SHUTOFF VALVE	HONEYWELL
106616	FLOW CONTROL VALVE	HONEYWELL
106616-0-3	FLOW CONTROL VALVE	HONEYWELL
106616-1-1	FLOW CONTROL VALVE	HONEYWELL
106788B164	ACTUATOR	ITT
106788B165	ACTUATOR	ITT
108032-10	REGULATOR	HONEYWELL
108032-11	REGULATOR	HONEYWELL
108032-12	REGULATOR	HONEYWELL
108032-3	REGULATOR	HONEYWELL
108032-6	REGULATOR	HONEYWELL
108032-8	REGULATOR	HONEYWELL
108032-9	REGULATOR	HONEYWELL
108033-3	REGULATOR	HONEYWELL
108033-6	REGULATOR	HONEYWELL
109016-10-1	VALVE	HONEYWELL
109016-11-1	VALVE	HONEYWELL
109016-12-1	VALVE	HONEYWELL
109016-13-1	VALVE	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
109016-14-1	VALVE	HONEYWELL
109016-2-3	UNLOADING AIR SHUTOFF VALVE	HONEYWELL
109016-3-3	UNLOADING AIR SHUTOFF VALVE	HONEYWELL
109016-7	UNLOADING AIR SHUTOFF VALVE	HONEYWELL
109710-1-1	SHUT-OFF VALVE	HONEYWELL
109710-2-1	SHUT-OFF VALVE	HONEYWELL
109710-3-1	SHUT-OFF VALVE	HONEYWELL
109710-4-1	SHUT-OFF VALVE	HONEYWELL
109710-5-1	SHUT-OFF VALVE	HONEYWELL
109710-6-1	SHUT-OFF VALVE	HONEYWELL
109710-7-1	SHUT-OFF VALVE	HONEYWELL
109710-8-1	SHUT-OFF VALVE	HONEYWELL
109710-9-1	SHUT-OFF VALVE	HONEYWELL
12720-1	VALVE, STICK TRIM CONTROL	STERER
12720-11	VALVE, STICK TRIM CONTROL	STERER
12720-2	VALVE, STICK TRIM CONTROL	STERER
12720-21	VALVE, STICK TRIM CONTROL	STERER
130156-1	AIR CHECK VALVE	HONEYWELL
203430	COOLING TURBINES	HONEYWELL
203430	AIRCRAFT COOLING TURBINE	HONEYWELL
203430-1	COOLING TURBINES	HONEYWELL
203430-4	AIRCRAFT COOLING TURBINE	HONEYWELL
203430-4-1	COOLING TURBINES	HONEYWELL
203720-1	AIR CYCLE MACHINE	HONEYWELL
203720-2	AIR CYCLE MACHINE	HONEYWELL
203720-3-1	AIR CYCLE MACHINE	HONEYWELL
203745-3	AIR CYCLE MACHINE	HONEYWELL
203745-3-1	AIR CYCLE MACHINE	HONEYWELL
203745-4	AIR CYCLE MACHINE	HONEYWELL
203880-2	AIR CYCLE MACHINE	HONEYWELL
203880-2-2	AIR CYCLE MACHINE	HONEYWELL
203880-3	AIR CYCLE MACHINE	HONEYWELL
320362-3-1	VALVE, SOLENOID	HONEYWELL
3213722-1-1	REGULATING VALVE	HONEYWELL
3213722-2-1	REGULATING VALVE	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
3213722-3-1	REGULATING VALVE	HONEYWELL
3213722-5-1	REGULATING VALVE	HONEYWELL
321502-4-1	SHUT-OFF VALVE	HONEYWELL
34470	VALVE	HONEYWELL
3505786-1	AIR TURBINE STARTER	HONEYWELL
36E165-2QC	AIR TURBINE STARTER	PARKER
36E84-18	AIR TURBINE STARTER	PARKER HANNIFIN
376269-7	VALVE	HONEYWELL
38E73-4A	CONTROL VALVE	PARKER
38E73-6A	AIR CONTROL VALVE	HONEYWELL
38E73-7A	AIR CONTROL VALVE	HONEYWELL
392122-1	VALVE	HONEYWELL
392122-1	SHUTOFF VALVE	HONEYWELL
392122-1-1	SHUTOFF VALVE	HONEYWELL
3960308-1-1	VALVE	HONEYWELL
3960308-2-1	VALVE	HONEYWELL
396308-1-1	VALVE, SHUT-OFF	HONEYWELL
396308-2-1	VALVE, SHUT-OFF	HONEYWELL
396308-2-2	VALVE, SHUT-OFF	HONEYWELL
396308-3-1	VALVE, SHUT-OFF	HONEYWELL
398648-1-1	TEMP. CONTROL VALVE	HONEYWELL
398648-1-2	TEMP. CONTROL VALVE	HONEYWELL
398650-1-1	VALVE, SHUT-OFF	HONEYWELL
398652-1-1	ELEC. DIVERTER VALVE	HONEYWELL
398654-1-1	BUTTERFLY SHUTOFF VALVE	HONEYWELL
398654-1-2	BUTTERFLY SHUTOFF VALVE	HONEYWELL
398654-1-3	BUTTERFLY SHUTOFF VALVE	HONEYWELL
398654-1-4	BUTTERFLY SHUTOFF VALVE	HONEYWELL
570527	HYDRAULIC PUMP	VICKERS
571925-1-1	AIR CYCLE MACHINE	HONEYWELL
571925-2-1	AIR CYCLE MACHINE	HONEYWELL
571925-3-1	AIR CYCLE MACHINE	HONEYWELL
610354	HYDRAULIC PUMP	VICKERS
66039	HYDRAULIC PUMP	PARKER
66039-01	HYDRAULIC PUMP	PARKER

PART NUMBER	DESCRIPTION	MANUFACTURER
66039-02	HYDRAULIC PUMP	PARKER
67-2734-001	DUAL BUTTERFLY MOTOR OPERATED VALVE	HONEYWELL
67-2735-001	DUAL BUTTERFLY MOTOR OPERATED VALVE	HONEYWELL
695960-1	ACTUATOR SCREW-JACK	CALCO CONTROLS
695960-3	ACTUATOR SCREW-JACK	CALCO CONTROLS
695960-5	ACTUATOR SCREW-JACK	CALCO CONTROLS
695960-7	ACTUATOR SCREW-JACK	CALCO CONTROLS
8067-1A	ACTUATOR SCREW-JACK	CALCO CONTROLS
8067-2A	ACTUATOR SCREW-JACK	CALCO CONTROLS
8067-3A	ACTUATOR SCREW-JACK	CALCO CONTROLS
8067-4A	ACTUATOR SCREW-JACK	CALCO CONTROLS
81940-3	WATER SEPARATOR	HONEYWELL
979470-2-1	SHUTOFF VALVE	HONEYWELL
BYLB7606	VALVE ASSY	BARBER COLEMAN
DYLZ3990	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3990-1	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3990-2	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3990-3	DUAL BUTTERFLY VALVE AND ACTUATOR ASSE	BARBER COLEMAN
DYLZ3990A	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3991	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3991-1	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3991-2	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
DYLZ3991A	DUAL VALVE AND ACTUATOR ASSY	HONEYWELL
EA-1045-037	HYDRAULIC PUMP	VICKERS
EA-1045-037-1	HYDRAULIC PUMP	VICKERS
EA-1045-037-1A	HYDRAULIC PUMP	VICKERS
EA-1045-037-2	HYDRAULIC PUMP	VICKERS
EA-1045-037-2A	HYDRAULIC PUMP	VICKERS
EA-1045-037-2B	HYDRAULIC PUMP	VICKERS
EA-1045-039-2A	HYDRAULIC PUMP	VICKERS
EA1320-442-1	HYDRAULIC PUMP	VICKERS
MF30-3913-25ZE-5	HYDRAULIC MOTOR	VICKERS
MF30-3913-25ZE-S656-	HYDRAULIC MOTOR	VICKERS
MF30-3913-30ZE-5	HYDRAULIC MOTOR	VICKERS
MF30-3913-S159-2	HYDRAULIC MOTOR	VICKERS

PART NUMBER	DESCRIPTION	MANUFACTURER
MF30-3913-S228-2	HYDRAULIC MOTOR	VICKERS
MF42-3913-S159-2	HYDRAULIC MOTOR	VICKERS
MF42-3913-S159-2	HYDRAULIC MOTOR	VICKERS
MF60-3913-30ZG-5	HYDRAULIC MOTOR	VICKERS
MF60-3913-S215-2	HYDRAULIC MOTOR	VICKERS
MF69-3906-30-S553-4	HYDRAULIC MOTOR	VICKERS
MF69-3906-30-S553-4A	HYDRAULIC MOTOR	VICKERS
MF88-3913-S395-5A	HYDRAULIC MOTOR	VICKERS
MF9-3911-30Z	HYDRAULIC MOTOR	VICKERS
MPEV-032-2A	HYDRAULIC PUMP	VICKERS
MPEV3-032-2	HYDRAULIC MOTOR PUMP ASSEMBLY	EATON
MPEV3-032-2A	HYDRAULIC MOTOR PUMP ASSEMBLY	EATON
MS42-3913-S159-2C	HYDRAULIC MOTOR	VICKERS
PV3-044-38	HYDRAULIC PUMP	VICKERS
PV3-075-16	HYDRAULIC PUMP	VICKERS
PV3-075-4	HYDRAULIC PUMP	VICKERS
PV3-075-4A	HYDRAULIC PUMP	VICKERS