

PART NUMBER	DESCRIPTION	MANUFACTURER
103770-1	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-2	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-3	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-4	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-5	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-6	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-7	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103770-8	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-1	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-2	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-3	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-4	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-5	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-6	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-7	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-8	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
103772-9	CABIN PRESSURE OUTFLOW VALVE	HONEYWELL
1081100-1	ACTUATOR, NLG DOOR	MESSIER-DOWTY
126758-3	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-5	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-5-2	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-6	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-6-2	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-7	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-7	FLAP DRIVE ACTUATOR	HONEYWELL
126758-8	PNEUMATIC DRIVE ACTUATOR	HONEYWELL
126758-8	FLAP DRIVE ACTUATOR	HONEYWELL
126842-2-1	DIFFUSE VANE ACTUATOR	HONEYWELL
130158-1-1	VALVE, CHECK	HONEYWELL
160148-1	VALVE, TEMP CONTROL	HONEYWELL
16040-101	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-103	NOSE LANDING GEAR ASSY	MESSIER-DOWTY

PART NUMBER	DESCRIPTION	MANUFACTURER
--------------------	--------------------	---------------------

16040-105	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-107	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-109	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-111	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-113	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-117	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16040-119	NOSE LANDING GEAR ASSY	MESSIER-DOWTY
16300-101	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16300-102	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16300-103	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16300-104	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16300-105	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16300-106	STEERING ACTUATOR ASSEMBLY	MESSIER-DOWTY
16400-101	NLG DRAG BRACE ASSEMBLY	MESSIER-DOWTY
16400-103	NLG DRAG BRACE ASSEMBLY	MESSIER-DOWTY
16400-105	NLG DRAG BRACE ASSEMBLY	MESSIER-DOWTY
16480-101	NLG STEERING MANIFOLD ASSEMBLY	MESSIER-DOWTY
16520-101	NLG RETRACTION ACTUATOR ASSY	MESSIER-DOWTY
16600-101	NLG UPLOCK ASSEMBLY	MESSIER-DOWTY
16600-103	NLG UPLOCK ASSEMBLY	MESSIER-DOWTY
16650-101	STEERING CONTROL MODULE ASSEMBLY	MESSIER-DOWTY
16850-101	SOLENOID VALVE	MESSIER-DOWTY
17002-101	MAIN LANDING GEAR	MESSIER-DOWTY
17002-102	MAIN LANDING GEAR	MESSIER-DOWTY
17002-103	MAIN LANDING GEAR	MESSIER-DOWTY
17002-104	MAIN LANDING GEAR	MESSIER-DOWTY
17002-105	MAIN LANDING GEAR	MESSIER-DOWTY
17002-106	MAIN LANDING GEAR	MESSIER-DOWTY
17002-107	MAIN LANDING GEAR	MESSIER-DOWTY
17002-108	MAIN LANDING GEAR	MESSIER-DOWTY
17002-109	MAIN LANDING GEAR	MESSIER-DOWTY
17002-110	MAIN LANDING GEAR	MESSIER-DOWTY
17002-111	MAIN LANDING GEAR	MESSIER-DOWTY
17002-112	MAIN LANDING GEAR	MESSIER-DOWTY
17002-113	MAIN LANDING GEAR	MESSIER-DOWTY

PART NUMBER	DESCRIPTION	MANUFACTURER
17002-114	MAIN LANDING GEAR	MESSIER-DOWTY
17002-115	MAIN LANDING GEAR	MESSIER-DOWTY
17002-116	MAIN LANDING GEAR	MESSIER-DOWTY
17008-103	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-105	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-107	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-109	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-111	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-113	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17008-115	MLG SIDE STAY ACTUATOR ASSEMBLY	GE AVIATION SYSTEM
17051-101	UPLOCK ASSY, MLG	MESSIER-DOWTY
17319-103	AUXILIARY ACTUATOR	MESSIER-DOWTY
17319-105	AUXILIARY ACTUATOR	MESSIER-DOWTY
27000-3	SPOILERON POWER CONTROL UNIT ASSEMBLY	GOODRICH
27000-5	SPOILERON POWER CONTROL UNIT ASSEMBLY	GOODRICH
27000-7	SPOILERON POWER CONTROL UNIT ASSEMBLY	GOODRICH
27200-5	AILERON POWER CONTROL UNIT ASSEMBLY	GOODRICH
27200-7	AILERON POWER CONTROL UNIT ASSEMBLY	GOODRICH
27800-3	GROUND SPOILER ACTUATOR ASSEMBLY	GOODRICH
300013000-003	COWL ANTI-ICE VALVE	KAISER FLUID TECHN
319545-series	SOLENOID VALVE ASSEMBLY	HONEYWELL
319625-1	VALVE, SOLENOID	HONEYWELL
319625-5	VALVE, SOLENOID	HONEYWELL
319625-8	VALVE, SOLENOID	HONEYWELL
3202072-1	VALVE, CHECK	HONEYWELL
3202072-2-1	VALVE, CHECK	HONEYWELL
3202072-3-1	VALVE, CHECK	HONEYWELL
3202232-1	VALVE, CHECK	HONEYWELL
320482-1	VALVE, SOLENOID	HONEYWELL
3213876-1	VALVE, SHUT-OFF	HONEYWELL
3213876-10	VALVE, SHUT-OFF	HONEYWELL
3213876-11	VALVE, SHUT-OFF	HONEYWELL
3213876-2	VALVE, SHUT-OFF	HONEYWELL
3213876-4	VALVE, SHUT-OFF	HONEYWELL
3213876-6	VALVE, SHUT-OFF	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
3213876-9	VALVE, SHUT-OFF	HONEYWELL
3214442-2	VALVE, SHUT-OFF	HONEYWELL
3214442-3	VALVE, SHUT-OFF	HONEYWELL
3214442-4	VALVE, SHUT-OFF	HONEYWELL
3215622-1	VALVE, SHUT OFF	HONEYWELL
3215622-2	VALVE, SHUTOFF	HONEYWELL
3238470-1	ACTUATOR BALL SCREW	HONEYWELL
3238470-2	ACTUATOR BALL SCREW	HONEYWELL
3272570-2	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-3	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-4	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-4	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-5	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-6	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-7	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-8	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3272570-9	THRUST REVERSER BALLSCREW ACTUATOR	HONEYWELL
3289590-2	VALVE, BUTTERFLY	HONEYWELL
3289590-3	VALVE, BUTTERFLY	HONEYWELL
3291024-5	VALVE, SHUT-OFF	HONEYWELL
3291024-6	VALVE, SHUT-OFF	HONEYWELL
350023000	CHECK VALVE	TACTAIR
3505188-11	AIR TURBINE STARTER	HONEYWELL
3505188-7-1	AIR TURBINE STARTER	HONEYWELL
3505188-7-2	AIR TURBINE STARTER	HONEYWELL
3505188-7-3	AIR TURBINE STARTER	HONEYWELL
3505188-7-4	AIR TURBINE STARTER	HONEYWELL
3505188-9	AIR TURBINE STARTER	HONEYWELL
35170-16	ELECTROMECHANICAL ROTARY ACTUATOR	HONEYWELL
35170-3	ELECTROMECHANICAL ROTARY ACTUATOR	HONEYWELL
3615853-1	VALVE ASSY	HONEYWELL
3880410-10	VALVE ASSY	HONEYWELL
3880410-14	VALVE ASSY	HONEYWELL
3880620-2	VALVE ASSY	HONEYWELL
3888134	VALVE, SOLENOID	HONEYWELL

PART NUMBER	DESCRIPTION	MANUFACTURER
398724-1-1	VALVE, SHUT-OFF	HONEYWELL
398724-1-2	VALVE, SHUT-OFF	HONEYWELL
570347	HYDRAULIC PUMP	EATON AEROSPACE
692545-1	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-10	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-11	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-12	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-13	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-14	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-17	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-2	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-3	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-400	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-500	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-6	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-7	SOLENOID SHUTOFF VALVE	HONEYWELL
692545-9	SOLENOID SHUTOFF VALVE	HONEYWELL
710586	CHARGE PUMP	HAMILTON SUNDSTR
712801	SCAVENGE PUMP	HAMILTON SUNDSTR
721863	UPLOCK	HAMILTON SUNDSTR
728316	UPLOCK ACTUATOR ASSEMBLY	HAMILTON SUNDSTR
728431B	EJECTION JACK AND HOSE ASSY	HAMILTON SUNDSTR
728431C	EJECTION JACK AND HOSE ASSY	HAMILTON SUNDSTR
731879	EJECTOR PUMP	HAMILTON SUNDSTR
769150-3	AIR CYCLE MACHINE	HAMILTON SUNDSTR
778686-3	VALVE, SHUT-OFF	HAMILTON SUNDSTR
778686-4	VALVE, SHUT-OFF	HAMILTON SUNDSTR
778695-1	VALVE, SHUT-OFF	HAMILTON SUNDSTR
778695-3	VALVE, SHUT-OFF	HAMILTON SUNDSTR
778728-4	RECIRCULATION FAN	GE AVIATION SERVIC
778728-6	RECIRCULATION FAN	HAMILTON SUNDSTR
778728-8	RECIRCULATION FAN	GE AVIATION SERVIC
782790-11	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-13	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-15	AIR CYCLE MACHINE	HAMILTON SUNDSTR

PART NUMBER	DESCRIPTION	MANUFACTURER
782790-17	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-3	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-5	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-7	AIR CYCLE MACHINE	HAMILTON SUNDSTR
782790-9	AIR CYCLE MACHINE	HAMILTON SUNDSTR
808440-1	VALVE, DUAL BYPASS	HAMILTON SUNDSTR
808440-2	VALVE, DUAL BYPASS	HAMILTON SUNDSTR
808440-3	VALVE, DUAL BYPASS	HAMILTON SUNDSTR
816101-2	TEMPERATURE CONTROLLER	HAMILTON SUNDSTR
816101-4	TEMPERATURE CONTROLLER	HAMILTON SUNDSTR
848847	VARIABLE DISPLACEMENT AC ELECTRICAL DRIV	EATON AEROSPACE
849557	HYDRAULIC MOTOR PUMP	VICKERS
852D100-19	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
852D100-21	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
852D100-23	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
852D100-25	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
852D100-9	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-10	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-10	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-11	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-12	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-13	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-14	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-17	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-18	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-19	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-20	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-21	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-22	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-23	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-24	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
853D100-9	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-10	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-11	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-12	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE

PART NUMBER	DESCRIPTION	MANUFACTURER
854D100-19	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-20	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-21	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-22	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-23	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-24	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
854D100-9	ACTUATOR-INBOARD/OUTBOARD FLAP	EATON AEROSPACE
865D100-7	POWER DRIVE UNIT, FLAP	EATON AEROSPACE
865D100-7	POWER DRIVE UNIT/FLAP SYSTEM	EATON AEROSPACE
887055	HYDRAULIC PUMP	VICKERS
898930-10	PRESS REG VALVE	HONEYWELL
898930-3-1	PRESS REG VALVE	HONEYWELL
898930-7-1	VALVE, SHUT-OFF	HONEYWELL
898930-7-2	VALVE, SHUT-OFF	HONEYWELL
898930-8	VALVE, SHUT-OFF	HONEYWELL
979558-1	VALVE, SHUT-OFF	HONEYWELL
979558-2	VALVE, SHUT-OFF	HONEYWELL
979558-3	VALVE, SHUT-OFF	HONEYWELL
979558-4	VALVE, SHUT-OFF	HONEYWELL
979558-8	VALVE, SHUT-OFF	HONEYWELL
979558-9	VALVE, SHUT-OFF	HONEYWELL
979626-2-1	VALVE, SHUT-OFF	HONEYWELL
979626-3-1	VALVE, SHUT-OFF	HONEYWELL
979626-4-1	VALVE, SHUT-OFF	HONEYWELL
979626-5-1	AIR SHUT-OFF VALVE	HONEYWELL
979626-6	VALVE, SHUT-OFF	HONEYWELL
979627-2	VALVE, SHUT-OFF	HONEYWELL
979627-3	VALVE, SHUT-OFF	HONEYWELL
979627-4	VALVE, SHUT-OFF	HONEYWELL
979998-1	VALVE, SHUT-OFF	HONEYWELL
979998-2	VALVE, SHUT-OFF	HONEYWELL
979998-3	VALVE, SHUT-OFF	HONEYWELL
AL00102	LINEAR ACTUATOR	LUCAS AEROSPACE
MPEV3-012-2B	HYDRAULIC PUMP	VICKERS
MPEV3-012-2B	VARIABLE DISPLACEMENT AC ELECTRICAL DRIV	EATON AEROSPACE

PART NUMBER	DESCRIPTION	MANUFACTURER
PV3-032-11	HYDRAULIC PUMP	EATON AEROSPACE
PV3-044-48	HYDRAULIC PUMP	VICKERS